Dejavoo X8

Power

Ethernet (IP)

(REAR)

RDM Imager
Either USB

(BOTTOM)

Telephone
Line

RS   PINPAD MODEM

REAR/BOTTOM VIEW

The interconnecting cable is a Standard "A" to "A" USB Cable.
Do not use a transfer cable.

RDM EC-7014f

The RDM EC-7011f can also be used, since images upload via the terminal.

| POWER | USB | AUX | COM | TEL |

Power

Connect to
Terminal

Not Required on
this Terminal

REAR VIEW

If the merchant is processing Check21,
the "Franking Assembly" **MUST NOT** be installed.