Dejavoo V-Series

RDM
Imager

USB COM1 COM2

Ethernet

Power

LAN LINE TEL

Telephone

BOTTOM VIEW

The interconnecting cable is currently unknown.

RDM EC-6014f

The RDM EC-6011f can also be used, since images upload via the terminal.

POWER USB AUX COM TEL

Power

Connect to
Terminal

Not Required on
this Terminal

REAR VIEW