Dejavoo V-Series

RDM Imager

USB COM1 COM2

Ethernet

Power

Telephone

LAN LINE TEL

## BOTTOM VIEW

The interconnecting cable is currently unknown.

RDM EC-7014f

The RDM EC-7011f can also be used, since images upload via the terminal.

POWER | USB | AUX | COM | TEL

Power

Connect to Terminal

Not Required on this Terminal

REAR VIEW