

Item #: **C-2**

Check: 1 of 1

This check is designed to configure a Magtek Mini MICR check reader to interface with a Verifone Omni/VX terminal.

Insert this check, beginning on the left side of the reader, with the check face towards the inside of the reader. After successful configuration, the green LED will blink 8 times.

If at any point the LED turns red, repeat this process until successful configuration is achieved.

THIS IS NOT A TEST CHECK

Please cut as close to the line as possible to ensure readability

For Technical Assistance

Contact: 1-877-438-3249

© Paya Services 2018



Item #: **C-2**

Check: 1 of 1

This check is designed to configure a Magtek Mini MICR check reader to interface with a Verifone Omni/VX terminal.

Insert this check, beginning on the left side of the reader, with the check face towards the inside of the reader. After successful configuration, the green LED will blink 8 times.

If at any point the LED turns red, repeat this process until successful configuration is achieved.

THIS IS NOT A TEST CHECK

Please cut as close to the line as possible to ensure readability

For Technical Assistance

Contact: 1-877-438-3249

© Paya Services 2018



Item #: **C-2**

Check: 1 of 1

This check is designed to configure a Magtek Mini MICR check reader to interface with a Verifone Omni/VX terminal.

Insert this check, beginning on the left side of the reader, with the check face towards the inside of the reader. After successful configuration, the green LED will blink 8 times.

If at any point the LED turns red, repeat this process until successful configuration is achieved.

THIS IS NOT A TEST CHECK

Please cut as close to the line as possible to ensure readability

For Technical Assistance

Contact: 1-877-438-3249

© Paya Services 2018



Item #: **C-2**

Check: 1 of 1

This check is designed to configure a Magtek Mini MICR check reader to interface with a Verifone Omni/VX terminal.

Insert this check, beginning on the left side of the reader, with the check face towards the inside of the reader. After successful configuration, the green LED will blink 8 times.

If at any point the LED turns red, repeat this process until successful configuration is achieved.

THIS IS NOT A TEST CHECK

Please cut as close to the line as possible to ensure readability

For Technical Assistance

Contact: 1-877-438-3249

© Paya Services 2018

